


SIDEWINDER

Quick Start Guide




1


Unpack Sidewinder skates and accessories.




Sidewinder
skates



Drive
ratchets




Sidewinder
Transits



Adapter
yokes





Steering
tools



Kickstands

2


Install the adapter yokes to each skate and open one wing. Align the closed wing with the lowest upright pin holes. Insert the pins.



To stand the skate upright independently, insert the kickstand into the three holes on the skate.


3

Close the open wing. Make sure the sliding lock drops completely.



4

Using the ratchet, raise the lift mechanism to lift the fixture.



5

Lower the fixture. Uninstall skate and adapter yokes by opening yoke wings.

